

# **OWNER'S TECHNICAL MANUAL**

LED Slimline Work Light

20088

February 2019

### **Description**

The Alemlube 20088 LED Slimline Work Light, being only 11mm thin, is the ultimate workshop inspection light to reach into tight and restricted spaces. Complete control over brightness is achieved by turning a stepless dimming switch for the level of illumination suitable for your specific job at hand.

Special features include a super strong magnet in the circular base and the ability to rotate the light around 360°. High moisture intrusion and impact resistance ratings protect the 20088 LED Slimline Work Light to enhance its reliability and longevity in the workshop.

#### **Technical Details**

Item No.	20088
Light Source	High Power COB LED - Main Light High Power SMD LED - Top Light
Luminous Power	ca. 60-700 lm - Main Light (Min-Max) ca. 120 lm - Top Light
Operating Time	ca. 16-1.5h-MainLightFullPowerMode ca. 9.5 h - Top Light
Battery Specification	Li-lon 3.7 V, 2600 mAh, 9.62 Wh
Charging Time	ca. 4 h
Charging Input	DC 5V 1A
Degree of Protection	IP 54, IK 07
OperatingTemperature	-10 °C to +40 °C



## 20088



## **OWNER'S TECHNICAL MANUAL**

### **LED Slimline Work Light**

### Safety Warning and Precautions

- 1. Do not open the device.
- 2. Do not look directly into the light emitting lamp Risk of eye injuries!
- 3. Do not operate in direct sun light or extreme temperature conditions
- **4.** Operating temperature, -10°C to +40°C.
- 5. Keep away from children! Children should be supervised in order to ensure that they do not play with the device!

#### **Operating & Charging Procedure**

- 1. 20088 operating mode as below
  - Press the switch first time, top light switches on.
  - Press the switch second time, top light switches off.
  - Adjust the stepless switch to change brightness of the whole light.
- 2. Switch lamp off and connect with USB charger during charging.
- 3. The battery indicator will blink during charging.
- 4. The battery indicator will stay lit after the charging is finished.
- 5. If the battery indicator did not light up, please remove the charger and try again.
- **6.** Always only use the recommended charger to charge the lamp. The use of a NON-recommended charger can lead to a fire and destroy the lamp.
- 7. Before taking the work light into service for the first time charge it for 4-5 hours.
- 8. Fully charge the work light before it is stored for a longer period.

### Safety Instructions

- **1.** Do not use the device if there is damage to the housing, plug or cable.
- 2. Do not open the device! Repair work and replacing the rechargeable battery pack may only be carried out by an authorised electrician.
- 3. Carry out cleaning tasks only when the mains plug is removed from the mains power!
- **4.** There is a risk of short-circuit. Repairs on the device may only be carried out by commissioned and trained persons. Please contact your nearest authorized branch.
- 5. Protect the battery against heat, e.g., against continuous intense sunlight, fire, water, and moisture.
- **6.** If the battery is damaged or not used correctly fluids can leak from the battery. Avoid contact with these. Leaking battery fluids can lead to skin irritation or burns. Rinse off with water if you should come into contact. If the fluid gets into your eyes, ensure you get medical help.

### **Environmental Protection**

- 1. The device should not be discarded in the normal household waste under any circumstances.
- 2. Dispose of the device via an authorised disposal centre or your communal waste disposal facility.

  Observe the current applicable regulations. Contact your waste disposal facility in the event of any doubt.

  Dispose of all packaging materials via an environmentally friendly disposal facility. Rechargeable batteries must not be disposed of in the household waste.
- 3. Return used rechargeable batteries to your dealer or hand them in to a battery collection facility.